

Merrychef Microcook MD1800

The Microcook MD1800 is a high powered commercial Microwave Oven



Main Design Features

- No Turntable - All parts of the cavity can be used.
- Keypad - Set time, and to use pre-programmed cooking cycles.
- Time Display - Displays remaining cooking time.
- Air Filter - Cleans air to avoid degradation of internal components.
- **MUST BE KEPT CLEAN.**
- Standby - Oven fans and Cavity Bulb switch off after five minutes if oven not used.

Main Operational Points

- Follow cooking instructions exactly.
- Keep oven clean at all times - fresh spillages are easier to remove.
- **DO NOT** obstruct air inlets - the oven will overheat if this happens.

Merrychef Microcook MD1800

The Microcook MD1800 is a high powered commercial Microwave Oven

Cleaning Instructions

EQUIPMENT:




SUITABLE GLOVES




*GOGGLES WHEN
SPRAYING CLEANER*




MICROWAVABLE BOWL



HOT WATER



CLEAN CLOTH




CLEAN CLOTH

METHOD:

Remember to isolate the oven from the mains



All exterior panels to be cleaned daily with a damp cloth. Stubborn stains may be removed with an approved sanitiser. Wash and dry air filter weekly.



Remove all food particles using a clean cloth. Place a microwavable bowl containing 1.5 litres of water in the oven, and cook on 100% for 9 minutes. Remove using oven gloves and wipe out cavity with a clean cloth. Rinse cloth, wring out and wipe door seals carefully.



HEALTH & SAFETY

Wear protective gear as listed. See material Data Sheet for more information.

In case of fault– Please call MERRYCHEF LTD on the hot line



01252 371000



01252 371007

Between 08:45 hrs – 17:00 hrs Monday to Friday

Answer phone at all other times.

You will be charged if the oven is DIRTY and no fault found.

Troubleshooting Tips

E:1 Door not shut

E:3 Invalid time set
Program position empty

No Lights Check plug
Check mains supply

HOW TO PROGRAM

Press and hold the "P" pad until the P appears and the colons in the time display flash.
Now enter the time and the power
Followed by a number key where you wish the program to be stored: For example – 1